



ALCO TACHO OPERATION INSTRUCTIONS FOR DRIVER'S

At the start of your journey:

1. Insert your Tachograph card
2. Wait for the card to be read
3. Set the Tachograph card to 'WORK'
4. Turn the ignition on – The immobiliser will now start to 'beep'
5. Please provide a breath test
6. The beeping will now stop
7. On a 'PASS' your engine will start

At the finish of your journey:

1. Remove the Tachograph card which will automatically reset for the next driver

Notes

- **Alcotacho ensures all drivers take a breath test**
- **Eliminates the reliance of the driver reset button**
- **Stops drivers exploiting 'timeout periods'**
- **Drivers always knows when a test is required otherwise the buzzer will sound**

