

# MERCEDES USER MANUAL (LJI 3740)

**KEYS-** thinnest key used to unlock and lock coach whilst also twisting the black dial to the left to unlock and to the right to lock.

**Getting in-** Then pushing the black button near the dial to open and close the door.

**Power-** There is no power switch on this coach.

**Heat/Aircon-** the heater /aircon control panel is located to the left of the steering wheel, the two dials are for driver heat and air flow direction (see chart) to control the passenger settings button **21** is for pax temp so select this the use button **22** to adjust and for fan speed use **19** then again **22** to adjust.

**15** turns on air conditioning, **18** is the webasto heater.

**Microphones-** two fitted one is near the front door ensure both radios are on and one mic is switched on should work, second mic is on driver seat button on dash to right of steering wheel is used to switch on then mic should work.

**Boiler-** to top up boiler open locker door here you will find a wheeled water storage container please remove hose connection before taking off the coach to top up and be sure to reconnect once fitted back in the coach. Back onboard the coach ensure switch is on (see chart) go to the middle and push the silver button located near the tap hot water will slowly start to feed through may take some time to heat up. **Issues** sometimes the pipes can get air locks go back to the locker disconnect hose and blow into them to try and eliminate any air locks

**Boiler Winter Prep** – to prevent damage in winter due to cold weather please drain the boiler. Unclip the hose connector in the locker then go back inside to drain the water until empty.

**Toilet-** open locker near the middle door here you will find a silver lever turn this lever to drop the toilet and use the hose connectors to top up flush water and sink water levels.

**Triangle-** second from last offside ski locker.

**Batteries-** Rear nearside ski locker along with main kill switch

**Oil/ water/coolant** – oil water and coolant are in the main locker as well as winter kit.

**Fuses-** Rear offside ski locker

**Spare bulbs-**

**Spare Belts-**



- |                      |  |
|----------------------|--|
| 1. N/A               | 13. Driver air flow direction            |
| 2. Sunblind nearside | 14. Driver Temp control                  |
| 3. Sunblind offside  | 15. Driver Aircon                        |
| 4. Radio             | 16. Passenger webasto/aircon             |
| 5. DVD               | 17. Inside Air Recycle                   |
| 6. Dash info button  | 18. Webasto                              |
| 7. N/A               | 19. Passenger fan selection 21 to adjust |
| 8. N/A               | 20. Passenger temp control 21 to adjust  |
| 9. Tracker           | 21. Passenger Heat/fan adjustment        |
| 10. Gears            |  |
| 11. Air recycle      |  |
| 12. Driver fan speed |  |



**22.** Driver overhead Light

**23.** Reading lights (down all on up individual)

**24.** Main lights (down bright up dim)

**25.** Door light

**26.** Traction control

**27.** DVD Screens

**28.** Assistance/stop

**29.** Air horn

**30.** Boiler/urn

**31.** Toilet

**32.** Hazard's

**33.** Roof hatch

**34.** Roof hatch

**35.** Front door

**36.** Middle door

**37.** CCTV monitor

**38.** Tachograph



39. Override door

40. Halt break

41. Break assist off

42. Ferry lift

43. Ferry lift reset

44. Assistance/stop

45. Regeneration (N/A)

46. USB

47. N/A

48. Driver mic

49. Distance sensor

50. Locker lock/unlock (lights on=unlocked)

51. Locker lock/unlock (lights on=unlocked)

52. Front lights

53. Driver floor heater

54. Front lights wash

55. Driver window

56. Mirror adjustment

57. Main lights

